

MAINTAIN

Before cleaning or other maintenance, the air purifier must be disconnected the power supply.

To ensure the effect of purification, please wipe dust gently from the air intake-holes with soft cloth regularly .

NOTE

Ensure that the air purifier is stable so as to avoid excessive vibration or falling.

The power supply voltage of this machine is DC-5V, please be sure to use the power input matched with this machine.

The air purifier should be over 20cm from the wall and other shielding objects.

If the product is sound or smell abnormally, or high temperature, please stop using it immediately.

Do not put finger and other objects into the protective net, and the air inlet or outlet.

keep hair or fabric away from the machine, so as not to get involved or block the intake or outlet.

Avoid using in high temperature, humidity and water area.

PARAMETER

size :	φ90mmx170mm(h)
voltage :	DC-5V
current :	0.3A max.
power :	2.0W
accessory :	usb power cord, manual


WARRANTY CARD

	BT.innotec
Model No.	CC-1 CarClean Can
Purchase Date	
Contact info	
Failure Cause	


BT.innotec

CC-1 CarClean Can


USER MANUAL



INTRODUCTION




FRONT



BACK




USE




POWER & MODE SWITCH

Click and the level will be in turn as follow:
POWER ON → SLEEP MODE → COMFORT MODE →
INJECTION MODE → POWER OFF.

RUNNING MODE

-  **SLEEP MODE:**
Ultra low noise operation, create a quiet sleep environment.
-  **COMFORT MODE:**
Run at a moderate speed.
-  **INJECTION MODE:**
Run at the maximum speed.

Attention:




UV-C LED can be installed in this product.
UV-C LED can effectively kill 99.9%
of viruses and various bacteria

BT.innotec

NOTE

In order to better performance of air filtered will use, please do not use close or paper wrap the product.



FILTER REPLACEMENT

The replacement period of the filter core is 1-3 months. The replaced method as follows:

- 1 Rotate the base anticlockwise

